



PLANETARY MIXER

LT7 MIXER

*Premium
Touchscreen
Interface*



PLANETARY MIXER LT7 MIXER



#	Parts list	Code
1	Flat beater	PM50405834
2	Wire whip	PM43603400
3	Dough hook	PM40207800
4	Oil cover	PM50405743
5	Safe guard	PM50405382
6	Bowl	PM50401048
7	Cover	PM46801100
8	Bottom cover	PM50405893
9	Locking nut	PM50304061
10	61903-Gear	PM50301071
11	Internal gear seat	PM50405882
12	Nylon tube	PM50202017
13	Main shaft	PM50405885
14	61901-Gear	PM50301069
15	Planetary gear	PM50405824
16	Operating shaft	PM50405634
17	Flat washer C	PM50313066
18	Plastic pad for operating shaft	PM50405636
19	Spring	PM50406040
20	Flat washer Ø12	PM50307016
21	Pad	PM50405905
22	Poly-V belt	PM50302109
23	Large pulley	PM46800100
24	Motor fixed base	PM46801300
25	Flat washer A 4mm×14mm	PM50313074
26	Elevated circle	PM50405871
27	Flat washer 4mm×16mm	PM50313075
28	Upper column welding assembly	PM46800900
29	Main shaft gear	PM46800600
30	Operating frame	PM46801200

PLANETARY MIXER LT7 MIXER

#	Parts list	Code
31	Operating frame cover	PM50405896
32	Spotlight	PM50599124
33	Bowl seat	PM50405872
34	Lower column welding assembly	PM46801000
35	Rubber pad	PM50405876
36	Small pulley	PM46800200
37	Electrical baffle	PM50405988
38	Electric motor	PM50501289
39	Microswitch mounting plate	PM50407010
40	Microswitch	PM50506057
41	Torsion spring	PM50406052
42	Stopper	PM50405880
43	Plastic pad	PM46801500
44	Connector	PM50514018
45	Lifting cover	PM50405875
46	Rail positioning block	PM50405879
47	Rail	PM50405878
48	Torsion spring	PM50406049
49	Holder	PM50405874
50	Pushing shaft	PM50405886
51	Pushing handle (painted)	PM46801400
52	Waterproof connector	PM50514015
53	Circuit board box	PM50405883
54	PCB	PM50508066
55	PCB cover	PM50405983
56	Switch panel	PM50402405
57	Mask	PM50405934
58	Touch control circuit board	PM50508068
59	Front label	PM50402387
60	Rotating rod	PM50405877